



OTEXIO

INSTRUCTIONS FOR USE PROTECSKIP®

Creation date : 05/22/2024

Version : V.2.0

The steps on an open skip (15 – 20 m³ max + multi-skip) :

Step 1 : Take the liner out of the box.

2nd step : Position yourself in the center of the width of the skip (door side or hook side).

Step 3: Unroll the bag to its full height, then throw it inside the skip, keeping the cross in hand.

Step 4: Position the cross in the center of the width and attach it to a hook in the skip.

Step 5 : Deploy the bag to cover a first corner, then fix it to all the exterior hooks of the skip up to the last one.



Steps for Open Skip (30 m³) :

Prerequisites : Plan for 9 welded hooks in each corner: 1 in the middle of the width at the bottom of the skip, 2 on each length spaced every 2 meters.

Step 1 : Take the liner out of the box.

Step 2 : Deploy the liner fully.

Step 3: Open the doors, enter, and go to the bottom of the skip.

Step 4: Hook the cross marked on the liner in the middle of the width of the skip as high as possible.

Step 5: Hook the liner in each corner at the bottom.

Step 6: Hook the bag along each length, moving backward gradually.

Etape 7 : Finish with the corners by the door and close it.

Steps for Covered Skip (15 – 20 m³ max) :

Prerequisites : It is necessary to install (weld, rivet) about ten hooks inside the skip, just below the sideboards, for attaching the liner. We can also supply magnetic hooks.

Step 1 : Take the liner out of the box.

Step 2 : Position yourself in the center of the width of the skip (door side or hook side).

Step 3: Flip the covers to the opposite side from where you are.

Step 4: Unroll the liner to its full height, then throw it inside the skip, keeping the cross in hand.

Step 5: Position the cross in the center of the width and attach it to the inside hook.

Step 6: Deploy the liner to cover a first corner, then fix it up to the center of the first length.

Step 7: Flip the covers to the opposite side.

Step 8: Retrieve the liner and continue the installation as described in step 6.



Discover PROTECSKIP® in video

