



OTEXIO

INSTRUCTIONS FOR USE PIERCING CABLES AND BAR

Creation date : 05/22/2024

Version : V.2.0

PIERCING ACCESSORIES

CABLE AND BAR



- 1- Remove the pin from the cable.
- 2- Slide the cable through the hatch designed for this purpose to pierce the waste and bring it out on the other side.
- 3- Reinsert the pin to secure the cable during transport.
- 4- Repeat the steps in reverse to remove it.

The maximum load a cable can handle is 5000kg. We recommend placing two piercing cables per compactor*.



- 1- Remove the pin from the bar.
- 2- Slide the bar through the hatch designed for this purpose to pierce the waste and bring it out on the other side.
- 3- Reinsert the pin to secure the bar during transport.
- 4- Repeat the steps in reverse to remove it.

The maximum load a bar can handle is 1450kg. We recommend placing two piercing bars per compactor*.



*Use only during transport.